

END OF TREATMENT (with Manual Drain)

- 1 Machine will flash “END OF THERAPY.”**
- 2 Push the down arrow and record the “I-Drain Volume.”**
- 3 Push the down arrow and record the “Total UF.”**
(Proceed with “manual drain” if necessary i.e. for Negative or Low UF)
 - a. Press arrow down button until machine will flash “Manual Drain”
 - b. Press the curved arrow button for manual drain to commence
 - c. When manual draining is finished, machine will flash “End of Therapy”
 - d. Proceed with step 2 & 3
 - e. If UF remains negative, redo manual drain steps twice & contact your PD nurse.
 - f. If UF is positive, proceed to step 4 to finish disconnection.
- 4 Press GO (green button).**
- 5 Machine will flash “CLOSE ALL CLAMPS.”**
- 6 Close all the clamps.**
- 7 Close the white valve on catheter extension set.**

- 8 Press GO (green button).**
- 9 Machine will flash “DISCONNECT YOURSELF/
CLOSE ALL CLAMPS.”**
- 10 Open minicap.**
- 11 Wash hands with antibacterial hand gel/lotion
thoroughly. Wait for hands to dry.**
- 12 Disconnect patient line from catheter using non-
touch technique.**
- 13 Press GO (green button).**
- 14 Machine will say “TURN ME OFF.”**
- 15 Turn off machine.**
- 16 Remove lines and discard.**
- 17 Discard PD effluent down the toilet or shower
drain. Get help as needed as drain bucket/bin may
contain over 10 L of fluid.**